

## TECH TIP

### AIR GAP ON SOME TOYOTAS

When the hub fits inside the pulley as it does with clutch part numbers: 48596, 48820, 48822, and 48827, it seems that you can't check the air gap.



Toyota has made checking the air gap a cinch by placing slots in the pulley.

The air gap is adjusted by adding or removing shims. The specification for this air gap is .016 to .030 inch.